



Optional :One Key

Snap Lock

DATASHEET



Providing Extra Security to your RJ45 Connections


The Snap Lock is a small but helpful innovation that could add another extra physical security to your RJ45 modular plug.

It works with every standard RJ45 modular plug, either the UTP and STP type.


Once the plug is equipped with the Snap Lock, as long as the plug is plugged in, it would be locked automatically. The un-locking tool is required to unlock the plug. See the following instruction to see how the Snap Lock really works.

HOW TO INSTALL

1. Trim the latch



2. Put it on




3. Complete!



HOW TO USE

1. Plug into RJ45 jack



2. Locked!



HOW TO UNLOCK

1. Plug in the key to bottom
2. Pull out the plug with key

